



AMBER AREA LIGHT GLARE SHIELD INSTALLATION

Locate the 4 mounting holes.



Add Glare Shield to fixture and
Install the 4 supplied screws.



Note: Any leaking light in the gaps between the fixture and shield will need to be sealed with black caulk (not included). This would be applied to the inside of the glare shield.